



JF150 SENSOR INSTRUCTIONS

TOOLS



1 X MULTI TOOL




MAGNET

INSTRUCTIONS



Start by removing the pedals



Using the multi tool remove all the screws



Remove either one or both sides of the casing



Locate the sensor on the left side of the bike



Remove the small screw from under the sensor



Use any kind of magnet to run over the sensor



Check the monitor to see if the digits change

ADVICE

Make sure to unscrew the right pedal anticlockwise and the left clockwise.

Any kind of magnet can be used for the test, for example a fridge magnet.

If there are no readings from your monitor before the test this could indicate the sensor is too far from the wheel, after the magnet has been ran over the sensor if there are still no readings this may indicate that it is a faulty sensor.