

If you have any further queries please contact our customer service team on 0121 328 7507 or email at 'contact@jllfitness.co.uk'

REPLACEMENT BRAKE PAD INSTRUCTIONS

TOOLS



1 X PLIERS



1X8MM SOCKET SET

INSTRUCTIONS



You will see the bolt on one side



And the nut on the other



Make sure to start by turning the resistance all the way down



Use the socket set to turn the nut anticlockwise



Then simply pull out the bolt



The brake pad should now be free to slide out



If you need to replace the bracket as well remove the two bolts underneath

ADVICE

The pliers and socket set are not apart of the assembly kit.

These can be purchased at local tool retailers.

Any tools can be used so long as they can grip the bolts to turn them.

You will need to replace the pad when it begins to look fluffy or worn, you may also hear a slight noise from the flywheel this will indicate the pad needs to be changed.

The length of time between replacing the brake pads will vary depending on the amount of use and the intensity of each workout.